

Oasis

Design by
Ann Kristin Einarsen

Care and use
instructions



Northern

Warnings

1. Indoor or outdoor use, but not below freezing point (0°C).
2. Be careful when unwrapping the product, not to damage the surface.
3. Terracotta is a natural and living material, and the unglazed surface might change colour tone over time. White lines may also appear due to salt leaving the clay.
4. Remove plastic pot from plant before planting in your new Oasis. The soil must have direct contact with the pot.
5. Do not overfill the bottom water container.
6. Read watering instructions for your plants.

Cleaning instructions

1. Clean using a soft, slightly dampened cotton cloth.
2. Avoid strong cleaning agents as it may damage and leave stains on the material.